

How to Apply HP PVC-free Wall Paper



With HP PVC-free Wall Paper, you can create custom-designed, truly unique wall decorations that enable a powerful combination of professional photography, professional interior design, and digital printing technology.

Not only can you create your own custom designs, but you can also easily apply and remove your wall decoration.



Recommended tools

1. Damp sponge
2. Spray bottle filled with water
3. Razor knife
4. Squeegee
5. Metal putty knife

This wall paper is prepasted—requiring only water to activate the glue—and is designed for easy application and clean removal¹. In fact, clean removal is covered by an HP warranty for HP PVC-free Wall Paper prints applied using standard industry methods to a well-prepared wall as described below². In addition to the instructions below, you may be interested in more detailed information on hanging wall paper. There are many good sources of this information, including the Residential Guide on the Wallcoverings Association website at wallcoverings.org.

Prepare the wall



The wall surface should be clean, dry, structurally sound and free of mildew, grease, or other stains, and free of irregularities in order to achieve the best hanging performance and complete removal when redecorating.

To apply on drywall. For best results, apply to a wall surface that has been painted with one coat of builder's primer and one coat of latex paint (note: this is typical of new construction; a wall surface that has been painted with a single coat of primer or a coat of satin or gloss paint is acceptable). The wall surface should be clean, smooth, and free of debris or contaminants.



To apply over paint. Painted walls should be primed, smooth, and free from debris. Check the wall surface to determine the condition of the paint adhesion. If the paint is old, damaged, or flaking, priming is highly recommended.

To apply to a wall previously covered with wall paper. Any old wall paper remaining should be removed as well as the old adhesive (remove by sanding or using adhesive remover). Primer should be applied to the wall surface that is clean, smooth, and free of the old adhesive.

To apply over paneling. Any grooves should be filled to achieve a smooth surface, then covered with an adhesion-promoting primer.

To apply to a wall currently covered with wall paper. Not recommended.

Note: Some images and printing profiles may create a small layer of excess ink on the printed wall paper. This excess ink may wash away as the wall paper is applied and does not damage the quality of the graphic.

Apply the wall paper

Follow these step-by-step instructions

1. Size, prime and clean all walls to remove dust and debris and assure proper adhesion. Allow primer to dry for 24 hours.
2. Backroll each wall paper panel to remove the curl.
3. Stack panels in order upside down with the first panel on top.
4. Spray the top panel evenly with water.
5. "Book" the panel by laying it glue-side up, than folding the two sides to meet in the middle. Let the panel set for five minutes. Then spray and book additional panels. (Avoid creasing the paper when booking.)
6. Hang the panel at corner or plumb line.
7. Unbook top section and secure to wall. Once top section is secure, unbook bottom section and press against wall.
8. Remove air and bubbles with squeegee.
9. Wipe with damp sponge downward and outward to remove any excess adhesive.
10. Repeat process with the other panels making sure there is proper overlap to match pattern.
11. When wall is completely covered, use razor knife to trim excess.
12. Wipe entire wall with damp sponge to remove excess water and adhesive.

• **Tip:** Do not over smooth—bubbles smaller than the size of a U.S. Quarter (about 24 mm in diameter) will dissipate as the wall covering sets.



¹ HP PVC-free Wall Paper can be easily removed from the wall. Residual adhesive can be easily wiped clean with water and a sponge.

² Some warranty limitations apply, see the HP PVC-free Wall Paper warranty statement at HPLFMedia.com/hp/mediawarranties.

